




The Freddy Tramp Oil Separator is designed to remove tramp oil from coolants in a variety of applications, including machine tool sumps, component washing systems and quench tanks.


The Tramp Oil Separator runs continuously, separating the oil from the coolant or water whilst the host machine is in operation.






Accessories

Ultraviolet Biological Control System







Models	Suction	Processing	Hold-	Dimensions	Weight	Price	Add for
	Lift	Rate	Up	(LWH)	(Pounds)		UV
	(Ft)	(GPM)	Volume				
			(Gals)				
Air	10	2	15	26 x 20 x 48	110 Dry		
					265 Wet		
Electric	6	2	15	27 x 20 x 48	110 Dry		
					265 Wet		

(Specifications and Prices subject to change without notice